


Digital Camera Directions

Taking Pictures

1. Slide the POWER switch to the right to turn on the camera.
2. Set the MODE dial to CAPTURE.
3. Press the round "DO-IT" button to see your image in the LCD Screen.
4. Press the SHUTTER button half-way down to lock in the camera auto focus.
5. Press the SHUTTER button completely down to take the picture. (Use Telephoto or Wide Angle to adjust your picture)



Viewing Pictures and Deleting Pictures


1. Set the Mode dial to REVIEW.
2. Press the DO-It button.
3. Press the ◀▶ view buttons to scroll through and view the pictures on the LCD.
4. To delete a picture, press the MENU button, choose the Trash Can, Do-It button, choose "picture" or "all pictures".

Transferring Pictures to the Computer

1. Connect the camera to your computer using the proper cable connections.
2. Save battery power by using the AC Adapter while transferring pictures.
3. Set the MODE dial to CONNECT.
4. Slide the POWER switch to the right to turn on the camera.

Opening Picture Transfer Application

1. Log in.
2. From the Macintosh HD, open the KODAK Picture Transfer program.
3. Choose path by clicking DESTINATION and choosing correct folder to save pictures in. Hint: You can create a new folder and call it "class pictures" or "field trip pictures", etc.
4. Select either Transfer ALL pictures from camera OR Transfer SELECTED pictures from camera. If you choose Transfer SELECTED pictures from the camera, you may preview your selections before downloading.



5. Transfer begins.
6. After transfer is complete, disconnect camera from computer and delete pictures from the camera.

Renaming Digital Images

1. Once transfer is complete, close windows, and open folder with images.
2. Click on the numbers under the image, it should turn blue.
3. Label the image. This will be helpful when importing images to other programs.

Importing Digital Images Into Other Programs

Open up application of choice.

AppleWorks - Go to File, drag to INSERT, follow path to digital pictures.

Kid Pix - Go to File, drag to OPEN, follow path to digital pictures.

Kid Pix Studio Deluxe - Go to File, drag to IMPORT A GRAPHIC, follow path to digital pictures.

Kid Works Deluxe - Go to PAINT bucket on page, select paintbrush on shelf, click FROM DISK, follow path to digital pictures.

Inspiration - Go to EDIT, drag to INSERT GRAPHIC, follow path to digital pictures.

HyperStudio - There are two choices. 1. Go to OBJECTS, drag to ADD A GRAPHIC OBJECT, follow path to digital pictures. OR 2. Go to FILE, drag to ADD CLIP ART, follow path to digital pictures.

Adobe PhotoDeluxe - Go to File, drag to OPEN FILE, follow path to digital pictures.

TimeLiner - Click GRAPHIC, click BROWSE, follow path to digital pictures.